Smart Lock
User Manual
(TT Version)

Respected users:
Thank you for purchasing the smart lock

With innovation and technology to improve the quality of life, to create the world" Seek survival by quality, seek development by service" business philosophy. In the intelligent lock industry, constantly improve product quality system. I keep up with the pace of the Times has always been in the forefront of the industry, has always been unswervingly for the people property security escort!

From products to services, we have always sought to provide you with a safe location intimate comfortable service! Thank you for your support of Smart Lock!

disclaimer:

We have done our best to ensure that the information provided in this manual is correct and reliable, but we can not fully guarantee that errors occurred before and during the printing process.

Sometimes we may upgrade products to improve the performance, reliability, and security of components and systems. This may not be consistent with the instructions, but it does not affect the actual operation. If there is any change without notice, please understand! The company will regularly update the content, in case of doubt, please call the company for advice. All the contents of this manual shall be interpreted by the company. The functions described in this manual shall not be used as a reason for special use of this product. The company shall not be liable for any accident or damage caused by the wrong operation of the customer.

Catalogue description

Safety precautions	3
Dimension drawing of intelligent lock	4
SCHEMATIC DIAGRAM OF INSTALLATION OF DOUBLE tongue lock body	5-6
Installation Schematic diagram of smart Lock	7-9
Function setting menu operation instruction	10-12
Use the apartment version of LOCK	13-20
Other notes	21
System parameter	23

Safety precautions

1. As a high-tech product, the quality of the installation of the intelligent door lock directly affects the later use situation and service life of the door lock. It is recommended that you install the door lock after the room has been decorated. Please select a professional installer to install the door lock, installation personnel must strictly in accordance with the company's installation standards for operation.

2. Do not use in environment with strong radiation, high magnetic field, high temperature and other corrosive materials, so as not to affect the performance and life of the door lock.

3. Please Install the lock as soon as the installation of the lock is completed, and restore the lock in case state. After the installation, please immediately set the settings of your electronic key, in case others open your door lock.

4. Please also replace the new (used TL1+) Alkaline Batteries, old and new batteries can not be mixed use. When the electrification, keep the intelligence door lock company that professional technical staff to serve you, to ensure for you the real assured.

5. Please read this manual carefully before use. If you have any questions, you can call our customer service center or manufacturers Service Center. the company that company has professional technical staff to serve.

6. In response to the national regulations on the administration of articles prohibited from posting and delivery, this product is not supplied with batteries.

System parameter

Power supply: 4.5 v, four 7.4 batteries
Power input: STATIC CURRENT : <30uA
Working Current : <100mA
TYPICAL STATIC CURRENT : <10mA
Administration number: Group 9
Opening Current number: <100
Opening Fingerprint number: +100
Opening Card number: <100
Password length: 6-8 bits
Virtual code length: 1000s
LOW VOLTAGE ALARM VOLTAGE: 4.5/0.2V
Unlocking mode: Fingerprints, Credit Cards, passwords, keys
Working Current: <30uA
Working Humidity: %20-90%
relative humidity: %20-90%
working temperature: -10℃-40℃

Other notes

1)The system automatically enters the invalid input state, the invalid input state lasts for 90 seconds, when the unauthorized information is input more than 5 times within 5 minutes.

2)When the voltage is lower than 4.5 v, every unlock will automatically alarm, after the alarm, the door lock can be unlocked 200 times, after the number of times each unlock delay of 5 seconds, be sure to change the new battery before the number of unlocking times.

3)Password protection: When the password opens the door, enter the password as follows: XXX password XXX, you can add some irrelevant code before and after the password, and then press # to confirm. The password must be included in the input.

4)Every operation for more than 10 seconds does not operate the operating system will automatically exit.

5)Initialization settings: Long Press the back panel empty key 6-8 seconds initialization, after the completion of initialization all unlock information and records will be cleared (prudent operation).

6)Normally open mode off, press 5 #, voice prompt "please enter unlock information", input unlock information, voice prompt "normally open mode, please pay attention to lock".

7)When the normal mode is on, press "5 #" ,one after the other, and the voice prompts" The normal mode is off"

8)Lock function: After Press Lock Function, voice prompt "the door has locked" , at this time ordinary users can not open the lock, only the administrator can open the lock.

9)In the initial state, type "55566888 #" to switch between English and Chinese.

Configuration list

Serial number	Schematic diagram	Name of accessories	Quantity	Notes
1		Lock Body	1	
2		Lock Plate	1	
3		Latch box	1	
4	IC Card	IC Card	2	
5		Keys	2	
6		Square steel	1	
7		Cross head screw	1	
8		Cross head screw	2	
9		Mounting Stud	1	
10		Mounting Stud	2	

Thank you for your purchase of smart lock series products, when you open the box, please check the contents, if found missing in the box above, please contact your local distributor, to ensure your use.

Dimension drawing of intelligent lock

Inner Panel — Battery cover, Reverse lock switch, USB Port, Keyhole, Fingerprints, Password Swipe area

3.At the bottom of the Bluetooth key is a number of functional operation options, supporting the mobile phone authorization to set the fingerprint, password, IC card to add and delete.

Note: The user-defined Password option is set by the user, the Password of other function options is automatically generated by the system, the generated password must be activated within 24 hours to use once, otherwise it will automatically become invalid.

Redirection of the hand

(1) remove the cross screw in the drawing and according to the paper gauge
(2) If the holes are deviated, dip the lock body and panel assembly onto the entry plate, then correct the holes hard with appropriate

3. Drill holes according to the paper gauge

1. please refer to the paper gauge and drill the door holes according to the paper gauge.
(2) If the holes are deviated, dip the lock body and panel assembly onto the entry plate, then correct the holes hard with appropriate.

2.Change lock body direction (reversing)

When installing the lock body, the latching tongue is on the top. the square tongue is on the bottom, and the direction of closing the door. Otherwise, the direction of the latching face of the latching tongue faces the door opening direction should be adjusted as follows:
(1) turn the lock body upside down. (figure 2)
(2) press the slanting tongue firmly below the side plate, and rotate the lent block 180 degrees (fig 2) (3) push the slanting tongue into the slanting tongue hole. (figure 3)

1.Decide what way to open the door

Product harmonic
Family. Lock tricks. suitable for indoor door locks. suitable for 35-50mm doors.
People take out the door lock form on the left door for opening. Hinge on the right door for opening. Installation drawing face of the attaching direction of the door to adjust the direction of the handle, and install and attend tongue

SCHEMATIC DIAGRAM OF INSTALLATION OF DOUBLE tongue lock body

Special notes

Enter the interface in the Bluetooth signal range you can directly Click on the Bluetooth signal to unlock

---

(TT version)
Function setting key

1.Initial state, Click to add Bluetooth administrator settings, double click to enter the administrator password settings. long press 3 seconds to restore factory settings (T he initial password is "000#")

Note: Adding a Bluetooth Administrator can only be added in the initialized state.

Add a Bluetooth Administrator Action: Download and install the "TT lock"APP on the APP store or scan the Qr code directly

(TT version)

4.Install the lock body and buckle plate

5.Installation Diagram

1.Finally the front panel sheath into the rear panel the sheath plate, set
Back panel, Front panel

DOOR OPENING DIRECTION: Right

Cross screw

DOOR OPENING DIRECTION: Right
The triangle is rotated to the "double" position

Direction of opening: Left

DOOR OPENING DIRECTION: Right
The triangle is rotated to the "double" position
Accessories on "right" as shown in figure